

1/2" Dr. Injection Line Socket / Fuel Pipe Fittings 17x119mm

Item. No.: TATFT697D-05



Refer
to instructions



Wear
eye protection



Wear
protective gloves

Thank you for purchasing a our product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

SAFETY

- ✓ **WARNING!** Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using tools.
- ✓ **DO NOT** use tools if damaged.
- ✓ Maintain tools in a good, clean condition for best and safest performance.
- ✓ Ensure that a vehicle which has been jacked up is adequately supported with axle stands.
- ✓ Wear approved eye protection.
- ✓ Wear suitable clothing to avoid snagging.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Ensure all pieces are returned to the case and store this in a safe, dry, childproof location.

APPLICATIONS

- ◆ Facilitates the disassembly / assembly of Diesel injection pipes on injectors and other pipe fittings.
- ◆ For injection lines on MERCEDES-BENZ 100, 130, 314, 360, 360h, 352a, 346/355, 401, 402, 403, 407h, 615, 616, 617.
- ◆ Length: 119 mm.
- ◆ Special Wrench for BMW, Opel 2.5TD and Mercedes



WARNING: Please read these instructions carefully. Note the safe operational requirements, warnings and cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and or personal injury and will in validate the warranty. Please keep instructions safe for future use.